

---

---

## **Two Compartment Communicator w/Speech #1243**

---

---

### **USER'S GUIDE**



**For Technical Support:**

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)  
1-800-832-8697  
customer\_support@enablingdevices.com



50 Broadway  
Hawthorne, NY 10532  
Tel. 914.747.3070 / Fax 914.747.3480  
Toll Free 800.832.8697  
[www.enablingdevices.com](http://www.enablingdevices.com)

### Great for teaching language skills!

Our exclusive compartmentalized communicators are fun, easy to use, and perfect for teaching language skills (classification, sequence, function, opposites and comparatives). Place objects, pictures or words in each of the compartments. Now come with space for your objects and holders for your photos. Activating the switch plate plays the message while turning on one light at a time. Twenty seconds of total recording time. Requires 4 AA Batteries. Size: 11"L x 10½"W x 3"H. Weight: 1½ lbs.

#### Operation:

1. Locate the battery compartment at the bottom of the unit. Remove the cover and install four AA batteries into the holder, being sure to observe the polarity of the batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. To the left of the battery compartment is a red button. This button is used for recording messages into the Compartment Communicator. To record a message, press and hold the red button while at the same time holding down one of the two large colored buttons in one of the compartments. The microphone is located on the back of the unit, and looks like a black button. Speak into the microphone when recording. The unit will retain recorded information indefinitely, even if the battery is disconnected. Previously stored information will be erased every time a new recording is performed.
3. Playback volume can be adjusted using the control knob provided next to the red record button at the bottom of the unit.

4. The Compartment Communicator has two locations for placing Icons or Pictures. On the back of the unit there is a clear holding strip where Icons or Photos can be placed. There are also 3 x 3 icon holders. Changeable picture cards (Not included) slide behind the clear covers on the black 3-inch x 3-inch icon holders. Each icon holder is held in place with Velcro so that the user can quickly change the icons.

#### Important Notes:

1. The memory of this unit is capable of holding up to 20 seconds of speech information total. Maximum message length is 10 seconds for each segment.
2. The **Two Compartment Communicator** will shut off automatically after playback to preserve battery life. However, the device will remain on after recording.
3. If the unit fails to operate or operates incorrectly, disconnect the batteries for 20 seconds to reset the unit. If the unit still does not work correctly after the batteries are reconnected, replace all the batteries.

#### Care of Unit:

Two Compartment Communicator can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

**Do not submerge** the unit, as it will damage the contents and the electrical components.

**Do not use abrasive cleaners**, as they will scratch the surface of the unit