
Farmer Mac #2124

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)

1-800-832-8697

customer_support@enablingdevices.com



50 Broadway

Hawthorne, NY 10532

Tel. 914.747.3070 / Fax 914.747.3480

Toll Free 800.832.8697

www.enablingdevices.com

E-I-E-I-O!

Mac the cow comes decked out in his farmer attire and dances and sings “Old MacDonald Had a Farm” when you activate your capability switch. Song plays for 40 seconds after switch activation but can be stopped at any time by pressing your switch again. Great for encouraging singing and developing language skills. Size: 11"L x 9"W x 11"H. Requires 3 AA Batteries. Weight: 1½ lbs.

Operation:

1. Farmer Mac requires 3 AA batteries (Not included) to operate. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. The battery compartment is located under Farmer Mac. Open the Velcro flap then, using a Phillips head screwdriver open and remove the batter cover. Next install 3 AA batteries paying close attention to proper battery polarity.
3. Replace the battery compartment cover and secure it with the screw. Set the ON/OFF switch to ON.
4. Connect Farmer Mac to any external capability switch (not included) via the jack located at the end of his cord. Farmer Mac is equipped with a 1/8" jack for use with external capability switches with a 1/8" plug. Make sure you have pushed the switch plug all the way in. There should be no gaps. Farmer Mac can also be activated by squeezing his hoof.
5. Actuate your external capability switch or squeeze Farmer Mac’s hoof and he will dances and sings “Old MacDonald Had a Farm” Song plays for 40 seconds after switch activation but can be stopped at any time by pressing your switch again. Great for encouraging singing and developing language skills.

Troubleshooting:

Problem: Farmer Mac does not function correctly.

Action #1: Replace the batteries paying close attention to proper battery polarity.

Action #2: Make sure that the connection between the external capability switch is pushed in all the way. There should be NO gaps.

Action #3: Try your switch with another switch operated toy/device in an effort to rule out your switch as the source of the problems.

Care of Unit:

If you will not be using Farmer Mac for an extended amount of time, we recommend removing the batteries.

Do not submerge the unit in water, as it will damage the electrical components. Farmer Mac is surface washable only.