
Bubble Bandit #2254

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697
customer_support@enablingdevices.com



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Everyone loves bubbles!

Kids will love this crazy bandit. Just activate your capability switch and the Bubble Bandit will blow hundreds of bubbles out of its mouth. Great for developing tracking skills and teaching cause and effect. Size: 4½"L x 6½"W x 7"H. Requires 4 AA Batteries. Weight: 1 lb.

Operation:

1. Bubble Bandit requires 4 AA batteries (Not included) to operate. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. The battery compartment is located on the back of the Bubble Bandit. Turn the bubble blower to reveal the battery compartment cover. Using a Phillips head screwdriver unscrew the cover screw and install 4 AA batteries, paying close attention to proper (+) and (-) battery polarity.
3. Replace the battery compartment cover and secure with the screw. Connect to any external capability switch (not included) via the jack located on the side of the bubble blower. Bubble Bandit is equipped with a 1/8" jack for use with external capability switches with a 1/8" plug. Make sure your switch plugged in all the way. There should be no gaps.
4. Bubble Bandit can be used with or without an external switch. The ON/OFF switch is located in the top of the bubble blower. When using an external capability switch, the ON/OFF switch needs to be set in the OFF position. Actuate your external capability switch and the bubbles will start to flow! Once you release your switch the bubbles will stop.
5. When finished playing with Bubble Bandit turn the bubble blower OFF to prevent battery drain.

Troubleshooting:

Problem: Bubble Bandit does not function correctly.

Action #1: Check that all the batteries are installed, following proper (+) & (-) polarity. Also check that all batteries are fresh.

Action #2: Replace the batteries paying close attention to proper (+) and (-) battery polarity.

Action # 3: Make sure you have enough Bubble solution in the dipping troth. The Bubble solution should cover the Bubble Dippers completely.

Action #4: Make sure that the connection between the external capability switch and the jack is TIGHT. There should be NO gaps.

Action #5: Try your switch with another switch operated toy/device in an effort to rule out your switch as the source of the problems.

Care of Unit:

If you will not be using Bubble Bandit for an extended amount of time, we recommend removing the batteries.

Bubble Bandit can be wiped clean with any household multi-purpose cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not submerge the unit, as it will damage the contents and the electrical components.

Do not use abrasive cleaners, as they will scratch the surface of the unit.