

Mounting Options:

Each Panel has 4 mounting holes for wall mounting. **Please Note:** Mounting hardware is not included. You can use standard wall anchoring hardware found at hardware stores and Home Improvement Centers. Please consult one of their hardware associates for the proper mounting hardware based on your wall construction. In addition we also offer our Track System when mounting 3 or more Light Panels item No. 3116.



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697

customer_support@enablingdevices.com

Magical Spinning Light Wall Panel #2263W

USER'S GUIDE



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697

www.enablingdevices.com

32 colorful patterns!

Just press the big silver lens and watch the multi-colored light show and hear six different New Age tunes. The light show has 32 amazing and constantly-changing patterns of colored lights. Comes with On/Off adjustable volume and mild vibration. The wall panel can be used with our Track System (#3116) or mounted directly on a wall. Size: 13½"L x 15½" x 7¼"H. Requires 8 AA Batteries. Weight: 6¾ lbs.

1. Magical Spinning Light Panel requires 8 AA batteries (not included). Use Alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. The battery compartments are located under the magnetically held compartment on the top of the panel. To access the compartments lift up the access door and then remove the Phillips Head screws from each battery compartment cover. Install the AA batteries into each holder. When installing new batteries, always be careful to observe battery polarity. Replace battery covers and screws. Never mix old and new batteries together or different brands or types together. (See Photo).



2. Turn the ON/OFF/VOLUME knob clockwise, you will hear an audible click. Adjust to knob for desired volume level.
3. Just press the big silver lens and watch in amazement the mesmerizing multi-colored light show changing constantly at random while hearing upbeat music. The user will be captivated as the sphere spins and the silver lens is filled with 32 different amazing patterns of colored lights. As you hold your hand on the lens you will feel a slight vibration. It also comes with an off/on

volume which will allow you to turn the music down and just enjoy the riveting light patterns. The Magical Spinning Wall Panel can be used with our track system or just mounted straight on a wall.

Please Note: Not made to work flat on table top, Wall use only.

Troubleshooting:

Problem: Magical Spinning Light Panel's lights or music do not work when activated.

Action #1: Make sure the ON/OFF/VOLUME knob is turned.

Action #2: Check the Batteries for strength and for proper battery polarity. Replace if weak or dead.

Problem: Magical Spinning Light Panel does not light up or play music.

Action #1: Make sure the ON/OFF/VOLUME knob is turned ON and set at an audible level.

Action #2: Check the Batteries for strength and for proper battery polarity. Replace if weak or dead.

Problem: Magical Spinning Light Wall Panel runs not stop without touching the panel.

Action: Do not use Wall Panel laying down flat. This must be used upright and mounting to a wall or vertical surface to work properly.

Care of the Unit:

The Magical Spinning Light Panel can be wiped clean with any household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

Do not submerge the unit, as it will damage the electrical components.