

---

---

## Little Rock Star Guitar #1669

---

---

### USER'S GUIDE



#### For Technical Support:

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)  
1-800-832-8697

[customer\\_support@enablingdevices.com](mailto:customer_support@enablingdevices.com)



50 Broadway  
Hawthorne, NY 10532  
Tel. 914.747.3070 / Fax 914.747.3480  
Toll Free 800.832.8697  
[www.enablingdevices.com](http://www.enablingdevices.com)

### **Encourage interaction!**

This fun interactive guitar has been adapted with three easy-touch switches that play fun music and sound effects. Guitar has three groups of music, three play modes and an additional five light up musical buttons. *Size: 14"L x 9"W x 8½"H. Requires 3 AA Batteries. Weight: 2 lbs.*

### **Operation:**

1. Little Rock Star Guitar requires 3 AA batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types of batteries together.
2. The battery compartment is located on the back of the Guitar. Carefully remove the small screw from the cover using a Phillips head screwdriver, and lift the cover off. Observing proper (+) & (-) battery polarity, install 3 AA size batteries into the holder. Replace the cover and screw. Next set the volume switch to low or high. Set to one of three play modes via the blue knob at the top of the Guitar. In addition you can chose between three different groups of music via the green sliding ring also at the top of the Guitar.
3. Activate any one of the three large switches on the front of the base, or plug up to three of your own switches to play fun music and sound effects.
4. To use an external switch, plug your switch into the desired jack on the back of Guitar's base. Make sure your switch is plugged in all the way. There should be no gaps. Activating your switch will replicate the corresponding built in switch on the front of the base.

### **Troubleshooting:**

**Problem:** Little Rock Star Guitar does not work.

**Action #1:** Rotate (spin) the batteries within the battery compartment to ensure a good connection. Check that all batteries are installed properly.

**Action #2:** Check all batteries for freshness, if weak or dead replace with new batteries. Use an alkaline battery (E.G. Duracell or Energizer brand).

### **Care of the Unit:**

Little Rock Star Guitar can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

**Do not use abrasive cleaners, as they will scratch the surface of the unit.**

**Do not submerge the unit, as it will damage the electrical components.**