
Plasma Star #1673

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697
customer_support@enablingdevices.com



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Sound or switch activated!

Watch the flat panel disk show an amazing display of plasma light. This fantastic light disk responds to music, voice or your capability switch. Our Plasma Star encourages auditory development, sound making and increases visual attention. Size: 5"L x 7½"W x 5½"H. Requires 2 AAA Batteries. Weight: ¾ lb.

Operation:

1. The Plasma Star requires 2 AAA batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. To install the batteries in the Plasma Star, turn the unit over using a Philips Head screwdriver unscrew the two battery cover screws, then lift the cover off. Install 2 AAA batteries following proper (+) & (-) battery placement. Replace battery cover and screws. Turn the Plasma Star's ON/SOUND RESPONSE/OFF switch located on the top of the Plasma Star's disk to either ON or SOUND RESPONSE.
3. Plug your external capability switches into the female 1/8" jack on the Plasma Star. If your switch has a ¼" male plug, then you can use one of our #1170 ¼" to 1/8" adapters to make your switch compatible with this toy. Make sure that all connections are tight, there should be no gaps.
4. Activating your switch will make the Plasma Star display an amazing Plasma Light show for as long as the switch is activated. Once the switch is released the Plasma Light will stop The Pocket Plasma will also work without the use of a switch, by setting the ON/SOUND RESPONSE/OFF switch to SOUND RESPONSE. In this setting any nearby sound, voice, vocalization or music will activate the Plasma Light.

5. When you are finished using the Plasma Star turn the ON/SOUND RESPONSE/OFF switch to OFF, this will help conserve battery power. Leaving it ON or set to SOUND RESPONSE will drain the batteries out completely in a short amount of time.

Troubleshooting:

Problem: The Plasma Star does not work when my switch is activated.

Action #1: Make sure that you press all connections firmly together. Any gaps may interrupt electrical connection. The **ON/SOUND RESPONSE/OFF** switch needs to be set to **SOUND RESPONSE**.

Action #2: Make sure batteries are fresh.

Action #3: Try a different switch with the Plasma Star to rule it out as the source of the problem.

Problem: The Plasma Star works intermittently.

Action: Replace batteries in the Plasma Star.

Care of Unit:

The Plasma Star can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not submerge the unit in any fluids, as it will damage the contents and the electrical components.

Do not use abrasive cleaners, as they will scratch the surface of the unit.