
Suction Speaker #2214

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697
customer_support@enablingdevices.com



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Big sound!

We've adapted this fabulous water resistant speaker for your iPhone, Android smartphone or Bluetooth enabled devices. Activate your switch and the speaker plays, press it again and it pauses your music. Wireless functionality works up to 30 feet. Rechargeable battery lasts up to 4 hours. Also has a jack for connecting non-Bluetooth devices. Size: 2½"L x 2½"W x 2½"H. Requires Rechargeable Lithium Ion Battery (included). Weight: ¼ lb.

1. Before using the adapted speaker please charge the unit by plugging it into the included USB charging cable and charge via your computers USB port or with your Bluetooth device's USB/AC wall charging wart. The LED light on the adapted speaker will light up during charging and turn off when charging is complete. It will take approximately 3 hours to fully charge the unit. Please reference the OEM Guide for more charging options and features.
2. Now that your adapted speaker is full charged you can pair it with iPhone, Android smartphone or Bluetooth enabled devices.

Pairing your Speaker

1. Turn on the Bluetooth connection on your iPhone, Android smartphone or Bluetooth enabled device and enable the pairing mode of the Bluetooth connection. Make sure your device and the speaker are no more than 3 feet apart.
2. Turn on your speaker and look for the blinking light. When the adapted speaker is found, your device will display "HMDX Neutron" from the list of devices, and may be asked to enter the pairing code. Enter "0000" and press OK to establish the connection. To clear the pairing hold the Play/Pause button for 5 seconds.
3. **Note:** If the pairing process cannot be completed within 2 minutes after pairing mode is activated, the Adapted speaker will power off

automatically. Please repeat above steps again to pair your Bluetooth enabled device and the adapted speaker.

4. Plug any external capability Switch into the 1/8" jack located on the side of the adapted speaker. Make sure your switch is plugged in all the way, there should be no gaps. Your switch will do the same function as the Play/Pause button on the speaker itself.

Hooking Up Old School Audio

1. Plug one end of the cord into the speaker and the other into the headphone, line out or AUX jack on your device.
2. Turn on the speaker.
3. Hit Play on your device and adjust the volume.
4. You will have to control Play/Paus from your device, not the speaker or your switch.

Charging Info

Flashing RED: Low Battery

RED (when plugged in): Charging

Light turns off (when plugged in) Charged

Quick Flash BLUE: Pairing Mode

Slow Flash BLUE: Connected

RED: Hooking up old-school with a cord

Troubleshooting: See OEM guide.