
Marble Wall Panel #2295

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697

customer_support@enablingdevices.com



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Multiple Sensory Experience!

Cool translucent glass marbles move when you pass your hands across them. Press the marble plate to see light shining through the marbles. Panel provides an exciting visual and tactile experience. Can be used with our Track System (#3116) or mounted directly on a wall. Size: 13½"L x 15¼"W x 3½"H. Requires 4 C Batteries. Weight: 5½ lbs.

1. Marble Wall Panel requires 4 C batteries (not included). Use Alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. The battery compartments are located under the compartment on the top of the panel. The cover is spring loaded to keep it closed. To access the compartments lift up the access door and then remove the Phillips Head screws from each battery compartment cover. Install the C batteries into each holder. When installing new batteries, always be careful to observe battery polarity. Replace battery covers and screws. Never mix old and new batteries together or different brands or types together.
2. Turn the ON/OFF rocker switch to ON.
3. Cool translucent glass marbles move when you pass your hands across them. Press the marble plate to see light shining through the marbles. Panel provides an exciting visual and tactile experience. Once you release pressure on the marble plate the light will go out.

Troubleshooting:

Problem: Marble Wall Panel's lights do not work when activated.

Action #1: Make sure the ON/OFF rocker switch is turned ON.

Action #2: Check the Batteries for strength and for proper battery polarity. Replace if weak or dead.

Mounting Options:

Each Marble Wall Panel has 4 mounting holes for wall mounting. **Please Note:** Mounting hardware is not included. You can use standard wall anchoring hardware found at hardware stores and Home Improvement Centers. Please consult one of their hardware associates for the proper mounting hardware based on your wall construction. In addition we also offer our Track System when mounting 3 or more Panels item No. 3116.

Care of the Unit:

The Marble Wall Panel can be wiped clean with any household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

Do not submerge the unit, as it will damage the electrical components.