

---

---

## Mini Tropical Fish Aquarium #3271

---

---

### USER'S GUIDE



**For Technical Support:**

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)

1-800-832-8697

[customer\\_support@enablingdevices.com](mailto:customer_support@enablingdevices.com)



50 Broadway

Hawthorne, NY 10532

Tel. 914.747.3070 / Fax 914.747.3480

Toll Free 800.832.8697

[www.enablingdevices.com](http://www.enablingdevices.com)

Create a soothing ambiance with our mini aquarium. It lights up and the fish swim about when you press and hold your switch. Works with or without a switch. Size: 6½"L x 2"W x 4¼"H. Requires 3 AA Batteries. Weight: ¼ lb.

### Operation:

1. The Aquarium requires 3 AA batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable, heavy-duty or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. To install the batteries, carefully turn the unit to reveal the battery compartment. Using a Phillips head screwdriver remove the battery cover and screw, next install 3 AA batteries into the compartment. Please note to follow proper (+) & (-) battery polarity. Replace cover and screw.
3. Fill the tank with distilled water by removing the cap on the top of the tank, replace cap when done filling.
4. Next plug in your external capability switch into the female 1/8" jack, located in the side of the Aquarium. If your switch has a ¼" male plug, then order one of our #1170 ¼" to 1/8" adapters. Make sure the male plug is pushed all the way into the jack, there should be no gaps. Set the Aquarium's Power switch to OFF. You now can activate this toy with your switch.
5. When you activate your switch the Aquarium will turn the lights on and move the fish around the tank. Once you release your switch all functions will stop.

6. The Aquarium can also be used without a switch by simply turning the power switch to ON. The Aquarium will then run continually. If you plug a switch into the switch jack while the Aquarium is running it will turn the power OFF, you will then need to activate the switch for the Aquarium to run.

### Troubleshooting:

**Problem:** The Aquarium does not turn on when switch is depressed.

**Action #1:** Make sure that you press all connections firmly together. Any gaps may interrupt electrical connection. The ON/OFF switch needs to be set to **OFF**.

**Action #2:** Make sure batteries are fresh.

**Action #3:** Try a different switch with your Aquarium to rule out the Aquarium as the source of the problem.

### Care of Unit:

The Aquarium can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non-toxic biodegradable all-purpose cleaner.

**Do not submerge** the unit in any fluids, as it will damage the contents and the electrical components.

**Do not use abrasive cleaners**, as they will scratch the surface of the unit.