Cosmic Steering Wheel #779

USER'S GUIDE



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

enabling

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697
customer_support@enablingdevices.com

Brighten the day with lively entertainment!

Spin the wheel and stars and sparkles fly in the dome while music plays and bright lights shine. This is a spectacular cause and effect device, which will encourage individuals to reach out to activate the wheel. Size: 15"W x 11"H. Requires 4 C and 4 AA Batteries. Weight: $6\frac{1}{4}$ lbs.

Operation:

- The Cosmic Steering Wheel requires four "C" size batteries and four AA batteries, alkaline batteries Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types of batteries together.
- 2. The battery compartments are located on the underside of the unit. To install the batteries remove the small Phillips head screws from each of the black battery cases, then slide the covers off. Install the batteries paying careful attention to proper (+) & (-) polarity. Replace covers and screws.
- 3. To activate the toy, move the steering wheel either left or right. Enjoy the effects as the sequins flutter all about accompanied by music, light and vibration.
- 4. Once you stop moving the Cosmic Steering Wheel After a brief delay, the lights, music and vibration will stop.

Troubleshooting:

Problem: The music and/or the lights are not functioning, as they should.

Action: Check that all batteries are installed properly and are fresh.

Problem: The sequins are not fluttering and/or there is no vibration.

Action: One or more of the batteries that controls the sequins and vibration is weak, dead or installed incorrectly. Check these six batteries and replace them if need be, paying close attention to proper (+) and (-) battery polarity.

Care of Unit:

The Cosmic Steering Wheel can be wiped clean with any household multi-purpose cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

- Do not submerge the unit, as this will damage the contents and the electrical components.
- Do not use abrasive cleaners, as they will scratch the surface of the unit.