

---

---

## Discovery Tunnel #7907

---

---

### USER'S GUIDE



**For Technical Support:**

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)  
1-800-832-8697  
[customer\\_support@enablingdevices.com](mailto:customer_support@enablingdevices.com)



50 Broadway  
Hawthorne, NY 10532  
Tel. 914.747.3070 / Fax 914.747.3480  
Toll Free 800.832.8697  
[www.enablingdevices.com](http://www.enablingdevices.com)

*A fabulous multi-sensory experience!*

Slide your hand through the beaded curtain and experience auditory, visual and tactile stimulation. The white ball inside the tunnel lights up in many different soothing colors illuminating all the mirrors inside. At the same time you feel a slight vibration and hear one of six high quality mood-setting music pieces. The tunnel will provide hours of fun and relaxation. Also works with an external capability switch. Size: 14"L x 7½"W x 7½"H. Requires 10 AA Batteries. Weight: 3 lbs.

**Operation:**

1. The Discovery Tunnel requires 10 AA batteries to operate. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. Carefully turn over unit to reveal battery compartments. Remove the Phillips Head screws from the battery compartment covers. Next slide the battery compartment covers off and insert the "AA" batteries into the holder. Replace the covers and screws.
3. Set the ON/OFF/VOLUME switch to the desired VOLUME level. As you push your hand thru the draped beads into the tunnel of mirrors you will feel and see a white ball light up in many different colors. The changing colored ball brilliantly illuminates all the mirrors inside the tunnel and at the same time you will feel a slight vibration and hear one of six high quality mood setting music pieces.
4. If you leave your hand inside the tunnel of lights the music will change about every 20 seconds, but if you pull your hand out the music will stop at the end of that piece. The next music piece will play once you put your hand back in the tunnel. The octagon shaped mirrors inside does not only show a dazzling light show but you will also see the beads, your hand and your face in the mirrors.

5. To use the Discovery Tunnel with a switch, plug any capability switch into the 1/8" jack. When your switch is activated it will work as described in operations 3 & 4.

**Troubleshooting:**

**Problem:** The Discovery Tunnel does not work.

**Action #1:** Check the batteries for proper installation, as noted in operation No. 2.

**Action #2:** Check batteries for freshness, if weak or dead replace with new batteries.

**Action #3:** Make sure there is nothing obstructing the beads from moving.

**Action #4:** When using a switch, make sure all connections between the Discovery Tunnel and your switch are tight. There should be no gaps.

**Action #5:** Check your switch with another switch activated device to rule the Discovery Tunnel out as the source of the problem.

**Care of Unit:**

The Discovery Tunnel can be wiped clean with any household multi-purpose cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner. The ball can be removed for cleaning.

**Do not submerge** the unit, as it will damage the contents and the electrical components.

**Do not use abrasive cleaners,** as they will scratch the surface of the unit.