



Fish & Glow Spinner #2404

User's Guide

enabling
devices

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com

enabling
devices

50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Introduces a child to the world of cause and effect. Simply press your capability switch and create a swirling blend of colors and music, and watch as the fish spin around. Encourages visual attention and enhances auditory skills. Size: 9"L x 8"W x 9"H. Requires 5 AA Batteries. Weight: 1½ lbs.

Operation:

1. Fish & Glow Spinner requires five AA batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. Gently turn the unit over to reveal the black battery compartments. Carefully remove the small screw from the battery compartment covers using a Phillips head screwdriver, and slide the covers off. Observing proper (+) & (-) battery polarity, install batteries into the holders. Replace compartment covers and screws.
3. Connect the Fish & Glow Spinner to any external capability switch via the jack, located on the base of the unit. The Fish & Glow Spinner is equipped with a 1/8-inch jack, for use with capability switches with a 1/8-inch plug. If you need to use a 1/4- to 1/8-inch adapter use our No.1170 adapter. If purchased elsewhere, it must be a mono adapter, not stereo.
4. Make sure the rubber band is on both ends of the wheels on the bottom of the unit. (See photo on back of guide.) The Fish & Glow Spinner uses a standard #19 office rubber band.
5. Now actuate your external capability switch to create a swirling blend of colors and music, and watch as the fish spin around. Encourages visual attention and enhances auditory skills.

6. The Fish & Glow Spinner will only continue playing while the external capability switch is actuated. Once you release the switch, the Fish & Glow Spinner will stop.

Important Note:

The push down spinner top has been disabled for manual use; the Fish & Glow Spinner can only be operated with the use of a switch. Trying to use it manually will cause damage to the Press & Glow Spinner.

Troubleshooting:

Problem: The Fish & Glow Spinner does not spin and/or there is no music.

Action #1: Rotate (spin) the batteries within the battery compartment to ensure a good connection. Check that all batteries are installed properly.

Action #2: Check all batteries for freshness, if weak or dead replace with new batteries. Use an alkaline battery (E.G. Duracell or Energizer brand).

Action #3: Make sure the rubber band is on both ends of the wheels on the bottom of the unit. (See photo on back of guide.)

Action#3: Make sure that you have plugged your switch in all the way. There should be no gaps.

Action#4: Try your external capability switch with another toy/device to rule out the switch as the source of the problem.

Care of the Unit:

The Fish & Glow Spinner can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non-toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.