

Troubleshooting:

Action: Move to another place where radio frequency interference from another device or vehicle is not present.

Problem: The Fire Engine is not running.

Action: Make sure batteries in the Fire Engine and the controller are fresh and installed following proper (+) & (-) battery placement.

Problem: The Fire Engine is running intermittently.

Action: Replace batteries in the remote control and Fire Engine. Weak batteries will severely limit the normal transmitting range of your remote control.

Problem: Vehicle does not react, or reacts poorly to operation by transmitter.

Cause: High-frequency interference occurred near to high-voltage lines, transformers and some types of building.

Action: Avoid these if possible, or choose another place to operate the vehicle.

Care of Unit:

The Fire Engine can be wiped clean with any household multi-purpose cleaner and disinfectant.

Do not submerge the unit in any fluids, as it will damage the contents and the electrical components.



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697

customer_support@enablingdevices.com

Fire Engine #1546

USER'S GUIDE



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

To the rescue!

Watch our Fire Engine zoom around when you use its two-button remote control. Press the large yellow button and the Fire Engine goes straight, press the large red button and it turns. It's soft, safe and loads of fun! A great first remote control for beginners. Size: 6½"L x 4"W x 4"H. Vehicle requires 3 AA Batteries; Remote requires 2 AA Batteries. Vehicle weight: ¾ lb.

Operation:

1. To install the batteries for the remote controller, turn the big button controller over, remove the small Phillips Head screw from the battery cover then lift cover off. Install 2 AA batteries making note to follow proper (+) & (-) battery placement. Replace cover and screw. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. To install the batteries in the Fire Engine, using a Philips Head screwdriver unscrew the screw on the bottom of the Fire Engine, then lift the cover off. Install three AA batteries following proper (+) & (-) battery placement. As earlier mentioned follow battery recommendation. Replace the cover and screw. Turn the Fire Engine's ON/OFF switch located on the bottom of the Fire Engine to ON.
3. This remote controller allows the user to move the Fire Engine forward, and turn in a clockwise direction. Slight pressure on either big button switch will drive the Fire Engine in that direction. Once you release pressure on the switch the Fire Engine will stop.
4. When you are finished using the Fire Engine turn the ON/OFF switch on the Fire Engine to OFF, this will help conserve battery power. The remote controller does not have an ON/OFF switch, when not in use make sure noting is pressing the control switches, as this will drain the batteries in the controller regardless if the

5. Fire Engine is turned ON. If the Fire Engine is not going to be used for a long time, e.g. one month or longer, we recommend removing the batteries from the Fire Engine and controller during storage to prevent battery drain or leakage, which can cause damage to the Fire Engine and controller.

Troubleshooting:

Problem: The Fire Engine is not running.

Action: Make sure batteries in the Fire Engine and the controller are fresh and installed following proper (+) & (-) battery placement.

Problem: The Fire Engine is running intermittently.

Action: Replace batteries in the remote control and Fire Engine. Weak batteries will severely limit the normal transmitting range of your remote control.

Problem: Vehicle does not react, or reacts poorly to operation by transmitter.

Cause: High-frequency interference occurred near to high-voltage lines, transformers and some types of building.

Action: Avoid these if possible, or choose another place to operate the vehicle.

Problem: Loss of control.

Cause: Another radio control vehicle using the same frequency is operated near your vehicle. **Please Note: do not use two Fire Engines near each other.** Out of sight or the control range of distance. (15 to 20 feet.)

(Troubleshooting continued on back page)