
Giant Police Light #351

USER'S GUIDE

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com


Enabling Devices

385 Warburton Avenue
Hastings-on-Hudson, NY 10706
Tel. 914.478.0960 / Fax 914.478.7030
www.enablingdevices.com

Operation:

1. Giant Police Light requires 4 AA Batteries to operate. Alkaline batteries must be used (e.g. Duracell or Energizer Brands). Do not use rechargeable batteries because they supply a lower voltage and the unit may not perform as well. Never mix old and new batteries together or different brands or types together.
2. To install the batteries turn rectangular AC transformer box over to reveal the battery compartment. Next using a Phillips head screwdriver remove the small screw, and then slide the cover off. Install 4 AA batteries paying close attention to proper battery polarity.
3. Replace the battery compartment cover and secure it with the screw. Plug the end of the AC cord into a 110 Volt wall outlet. Connect Giant Police Light to any external capability switch (not included) via the jack located on the AC transformer box. Giant Police Light is equipped with a 1/8" female mono jack for use with external capability switches that have a 1/8" mono plug. Make sure you have a tight connection. There should be no gaps.
4. Actuate your capability switch and Giant Police Light will light up simulating a real Police Light.
5. Once you release the external capability switch, Giant Police Light will turn off. It will only stay on as long as your switch is activated.

Troubleshooting:

Problem: Giant Police Light does not function correctly.

Action #1: Replace the batteries paying close attention to proper battery polarity.

Action #2: Make sure that the connection between the external capability switches and the jacks are TIGHT. There should be NO gaps.

Action #3: Try your switches with another switch operated toy/device in an effort to rule out your switches as the source of the problems.

Care of Unit:

If you will not be using Giant Police Light for an extended amount of time, we recommend removing the batteries.

Do not submerge the unit in water, as it will damage the electrical components Giant Police Light is surface washable only.

The Giant Police Light can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

Do not submerge the unit, as it will damage the electrical components.