
Tornado Lamp #3270

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)

1-800-832-8697

customer_support@enablingdevices.com



50 Broadway

Hawthorne, NY 10532

Tel. 914.747.3070 / Fax 914.747.3480

Toll Free 800.832.8697

www.enablingdevices.com

Create a whirlwind of color and curiosity with this color changing vortex lamp when you press and hold your switch. Six LED lights provide wonderful soothing color. Great for visual attention and for illuminating your sensory space. Works with or without a switch. Size: 3½"L x 3½"W x 10"H. Requires 3 AA Batteries. Weight: 1 lb.

Operation:

1. Tornado Lamp requires 3 AA batteries. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. Turn the unit to over reveal the battery compartment. Carefully remove the screw from the battery compartment cover, and lift the cover off. Observing proper (+) & (-) battery polarity, install 3 AA size batteries into the holder. Replace the battery compartment cover and screw.
3. Set the Tornado Lamp to OFF for external switch use via the ON/OFF switch on the bottom of the unit. **Please Note:** The Tornado Lamp can work with or without the use of external switches.
4. Connect Tornado Lamp to any external capability switch via the input jack located on the side of the unit. Make sure you plug your switch in all the way. There should be no gaps. Press and hold your switch to create a whirlwind of color and curiosity with this color changing vortex. Six LED lights provide wonderful soothing color. Great for visual attention and for illuminating your sensory space. Once you release your all will stop. Tornado Lamp is equipped with a 1/8" jack. If you need to use a 1/4" to 1/8" adapter use our No.1170 adapter. If purchased elsewhere, it must be a mono adapter, not stereo.

Troubleshooting:

Problem: Tornado Lamp does not light up.

Action #1: Check the ON/OFF switch

Action #2: Rotate (spin) the batteries within the battery compartment to ensure a good connection. Check that all batteries are installed properly.

Action #3: Check all batteries for freshness, if weak or dead replace with new batteries. Use an alkaline battery (E.G. Duracell or Energizer brand).

Action #4: Make sure that you have your switch plugged in all the way. There should be no gaps.

Action #5: Try your external capability switches with another toy/device to rule out the switch as the source of the problem.

Care of the Unit:

The Tornado Lamp can be wiped clean with any mild household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

Do not submerge the unit, as it will damage the electrical components.