

Other Popular Toys:

Ring Around Bells #23

Dome Alone #69

Dome Alone with Switch #71

Mini Dome #72

Drum #80

Musical Rolling Pin #160

Musical Light Box #200

Stacking Blocks #359

Stacking Ring Cone #360

Musical Top #400

Vibrating Light #458

Vibrating Light with Music #459

Glitter Roll #696

Motorized Glitter Roll #697

Butterfly Light and Music Puzzle #922

For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com

Pouring Cup - #20

USER'S GUIDE


Enabling Devices

385 Warburton Avenue
Hastings-on-Hudson, NY 10706
Tel. 914.478.0960 / Fax 914.478.7030
www.enablingdevices.com

The Pouring Cup is an innovative toy that will provide hours of dramatic play. When activated by a capability switch, the top cup turns counterclockwise and pours liquid into the bottom cup. When activated by a second switch, the cup turns in the opposite direction, returning to the upright position.

Operation:

1. The Pouring Cup requires four AA batteries. Alkaline batteries are recommended because they last longer. Do not use rechargeable batteries because they supply lower voltage and the unit may not perform as well. The battery compartment is located at the back of the unit. When installing new batteries, always be careful to observe battery polarity.
2. Connect the unit to a double switch, such as the rocking plate switch (#860-large or #870-small), or to any two capability switches via the jacks, located on the back of the unit above the battery compartment. The Pouring Cup #20 is equipped with 1/8-inch jacks for use with capability switches with 1/8-inch connectors. If you need to use 1/4- to 1/8-inch adaptors, they must be mono adaptors, not stereo.

Troubleshooting:

Problem: The cup will not turn.

Action: Replace the batteries.

Care of Unit:

The Pouring Cup can be wiped clean with any household multi-purpose cleaner and disinfectant.

Do not submerge the unit, as it will damage the electrical components.

Do not use abrasive cleaners, as they will scratch the surface of the unit.