

---

---

# UFO Starship #1704

---

---

## USER'S GUIDE

---

**For Technical Support:**

Call our Technical Service Department  
Monday through Friday, 9 a.m. to 5 p.m. (EST)  
1-800-TEC-TOYS or 1-800-832-8697  
customer\_support@enablingdevices.com

---

  
**Enabling Devices**

385 Warburton Avenue  
Hastings-on-Hudson, NY 10706  
Tel. 914.478.0960 / Fax 914.478.7030  
[www.enablingdevices.com](http://www.enablingdevices.com)

Fantastic sensory stimulator!

Full of fun. Just pressing on the brown dots will give delightful sounds from space, as well as vibration or illuminating space lights. Size: 7"D x 1"H Requires 4 AA Batteries (Not included).

### **Operation:**

1. UFO Starship requires four AA batteries. The battery compartments are located under the base of the unit. Carefully turn the switch over, and then remove each battery cover with a small Philips screwdriver. Install new batteries, being careful to observe proper (+) & (-) battery polarity. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together.
2. Replace the battery case covers and secure them with the small screws. Do not over-tighten. Turn the ON/OFF/VOL knob to ON. Turning this knob clockwise turns the unit on as well as increases the volume, counterclockwise lowers the volume and turns the unit off.

### **Troubleshooting:**

**Problem:** The UFO Starship does not operate properly.

**Action # 1:** Make sure the batteries are in the battery compartment properly, and making good contact.

**Action # 2:** If the unit still does not work properly, replace the batteries.

### **Care of Unit:**

The UFO Starship can be wiped clean with any household multi-purpose cleaner and disinfectant.

**Do not submerge** the unit, as it will damage the contents and the electrical components.

**Do not use abrasive cleaners,** as they will scratch the surface of the unit