
Hello Kitty RC Car #1454

USER'S GUIDE



For Technical Support:

Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-832-8697
customer_support@enablingdevices.com



50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Super cute!

Have lots of fun driving Hello Kitty around. We've created a large, easy-to-activate remote control with three buttons – forward, turn and music/sound effects. Great for teaching cause and effect and encouraging visual tracking. Size: 7"L x 4"W x 5"H. Car requires 4 AA Batteries; Remote requires 3 AA Batteries. Weight: 2¼ lbs.

Operation:

1. To install the batteries for the remote controller, turn the big button controller over, remove the small Phillips Head screw from the battery cover then lift cover off. Install 2 AA batteries making note to follow proper (+) & (-) battery placement. Replace cover and screw. Use alkaline batteries only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Never mix old and new batteries together or different brands or types together. Set the ON/OFF toggle switch to ON.
2. To install the batteries in the Hello Kitty Car, using a Philips Head screwdriver unscrew the screw on the bottom of the car, then lift the cover off. Install 3 AA batteries following proper (+) & (-) battery placement. As earlier mentioned follow battery recommendation. Replace the cover and screw. Turn the car's ON/OFF switch located next to the battery compartment to ON.
3. This remote controller allows the user to move the car forward, turn and play music/sound effects. Slight pressure on either big button switch will drive the car in that direction. Once you release pressure on the switch the car will stop.
4. When you are finished using the Hello Kitty Car turn the ON/OFF switch on the car and the remote OFF, this will help conserve battery power and prevent accidental activation.
5. If the Hello Kitty car is not going to be used for a long time, e.g. one month or longer, we recommend removing the batteries from the car and controller during storage to prevent battery drain or

leakage, which can cause damage to the Hello Kitty Car and controller.

Troubleshooting:

Problem: The Hello Kitty Car is not running.

Action: Make sure batteries in the Hello Kitty Car and the controller are fresh and installed following proper (+) & (-) battery placement.

Problem: The Hello Kitty Car is running intermittently.

Action: Replace batteries in the remote control and Hello Kitty Car. Weak batteries will severely limit the normal transmitting range of your remote control.

Problem: Hello Kitty Car does not react, or reacts poorly to operation by transmitter.

Problem: Loss of control.

Cause: Another Hello Kitty Car operated near your vehicle. **Please Note: do not use two Hello Kitty Cars near each other.** Out of sight or the control range of distance. (15 to 20 feet.)

Action: Move to another place where interference from another device or vehicle is not present.